

FENCE POST REPAIR ANCHOR KIT

Heavy-Duty Steel Anchor · Fixes Leaning & Broken Fence Posts — No Digging, No Concrete Removal

2-PACK

HEAVY-GAUGE STEEL

OFFSET DESIGN

FITS 4x4 & 6x6 POSTS



WHAT'S IN THE BOX

- ✓ 2 × Steel Repair Anchors (offset design, pointed tip)
- ✓ 8 × Outdoor-Rated Lag Screws (black coated)
- ✓ 1 × Wood Pre-Drill Bit
- ✓ 1 × Hex Nut Driver Bit (for power drill)

Material: Heavy-gauge carbon steel, weather-resistant coating

Tools needed: Power drill + 3 lb hammer or small sledge

Install time: About 10–15 minutes per post

INSTALLATION IN 4 EASY STEPS

BEFORE YOU START: Straighten the post to vertical with a level, and clear away any loose soil or debris around the base so the anchor sits flush against the post.



1. POSITION

Hold the anchor flat against the post, offset bend just above the footing and pointed tip on the soil.



2. DRIVE IN

Place a wood block on top and hammer the anchor straight down beside the footing — the block protects the coating.



3. PRE-DRILL & 4. FASTEN

Pre-drill each hole into the post, then drive a lag screw into every hole. Snug firmly — do not overtighten.

HOW IT WORKS & PRO TIPS



The offset bend clears the existing concrete footing while the pointed shaft anchors deep into compact soil — no digging and no concrete removal required.

★ PRO TIPS FOR A SOLID INSTALL

- **Soft or wet soil?** Install on a dry day — compact soil grips the anchor much better.
- **Hard ground:** Wet the soil slightly and let it soak about 10 minutes before driving the anchor.
- **Badly rotted post?** Use two anchors on opposite faces of the same post for maximum support.
- **Protect the coating:** Always place a wood block on the anchor top before hammering (see Step 2).
- Check the screws once a season and re-snug if needed.

⚠ SAFETY & CARE

- **Call 811 before you drive:** check for buried utility lines before driving any stake into the ground (US & Canada).
- Wear safety glasses and work gloves during installation — steel edges and hammer strikes can cause injury.
- Keep children and pets away from the work area.
- This product reinforces an existing post. A post that is completely severed or hollow with rot should be replaced.
- Anchor tip is sharp — handle with care when unpacking.

Need Help? We've Got You.

Questions, missing parts, or installation trouble? Contact us through your Amazon order page (**Your Orders** → **Get Product Support**) and we'll respond within 24 hours.
Every kit is backed by our **12-month replacement warranty** — no questions asked.